


**HUMMER**

**H-500**


**DIGITAL ARGB CPU COOLER**

**USER MANUAL**


# 01.PACKAGE CONTENT

**A**


x1

**B**


x1

**C**


1 x

**D**

x2

**E**

x2

**F**

x2

**G**

x1

**H**

x4

**I**

x4

## 2.INTEL&AMD


AMD AM5/AM4:E,H,I

INTEL LGA 1851 /1700/1200/115X:C,D,H,I


**H**




**I**




**C**



**D**




**E**



**INTEL**


**AMD**

### 03.INTEL&AMD




# 04.INTEL-LGA 1851/1700/1200/115X


1




2




4






3



D




## 05.INTEL-LGA 1851/1700/1200/115X




## 06.AMD-AM5/AM4


1



2






3




AM4/AM5

## 07.AMD-AM5/AM4






## 08.INTEL&AMD




## 09.INTEL&AMD





CPU\_FAN

## 10. INTEL&AMD ARGB





## 11. INTEL USB



Connect to 9-pin USB

## 12.AMD USB



**Connect to 9-pin USB**

## 13. PRODUCT SOFTWARE

Go to NOX website, [www.nox-extreme.com](http://www.nox-extreme.com).

Go to the cooling system section and search for Hummer H-500.

You will find a link to download the software.

Install it and follow the instructions.

Enjoy Hummer H-500 Digital ARGB CPU Cooler.

POWERED BY  
**NOX**

[www.nox-extreme.com](http://www.nox-extreme.com)