




nox


**HUMMER**

**M-360<sub>LCD</sub>**


**USER MANUAL - MANUAL DE USUARIO**

# PARTS LIST / LISTA DE COMPONENTES


**A**



**B**




**C**




**D**



**E**



**F**



**G**

360×12  
240×8



INTEL:

**A**

**C**

**D**

**E**



AMD:




**C**




**D**

**F**


## RADIATOR INSTALLATION / INSTALACIÓN DEL RADIADOR





**A**

**LGA1851/1700**

**LGA115X/1200**





**1**




**2**












1

B



2





## CONNECTIONS / CONEXIONES

